## 2. Schedule SA07682

## A: MAINTENANCE SCHEDULE 1 SA07682G24

		MAINTENANCE INTERVAL																	
		[Number of months or km (miles), whichever occurs first]																	
	Months	3	7.5	15	22.5	30	37.5	45	52.5	_	67.5		82.5			_	112.5	120	Remarks
	× 1,000 km	4.8	12	24	36	48	60	72	81.4	96	108	120	132	144	156	168	180	192	
	× 1,000 miles	3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
1	Engine oil	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
3	Spark plugs					R				R				R				R	
4	Drive belt(s)					ı				ı				ı		R			
5	Camshaft Drive belt					ı				ı				ı		R			
6	Fuel line					(I)				(I)				(I)				ı	Note (1)
7	Fuel filter					(R)				(R)				(R)				R	Note (1)
8	Air cleaner element					R				R				R				R	Note (2)
9	Cooling system					ı				ı				ı				ı	
10	Coolant					R				R				R				R	
11	Clutch system			ı		ı		ı		ı		ı		ı		I		ı	
12	Transmission oil					ı				ı				ı				ı	
13	ATF					ı				ı				ı				ı	Note (3)
14	Front & rear differen-					ı				ı				ı				ı	
L	tial oil					_		<u> </u>						-		<b>.</b>		_	
15	Brake line			I		I		ı		I		I		I		l I		I	
16	Brake fluid					R				R				R				R	
17	Disc brake pads & discs					I								ı				ı	
18	Brake linings and drums					I				ı				I				I	
19	Parking brake			ı		ı		ı		ı		ı		ı		ı		ı	
20	Suspension			I		ı		ı		ı		ı		ı		ı		ı	
21	Wheel bearing			I		ı		ı		ı		ı		ı		ı		ı	
22	Axle boots & joints			ı		ı		ı		ī		ı		ī		ı		ı	
23	Tire rotation		ı	ı	ı	ı	I	Ī	ı	Ī	ı	i	ı	Ī	ı	İ	ı	ı	Note (4)
24	Steering system (Power steering)			I		I		I		ı		I		ı		I		I	
25	Supplement restraint system		Inspect every 10 years																

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

NÓTE:

- (1) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.
- (2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.
- (3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically damaged or ATF leaked.
- (4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less.

## B: MAINTENANCE SCHEDULE 2 SA07682G25

Item	Every	Repeat short distance drive	Repeat rough/muddy road drive	Extremely cold weather area	Salt or other corrosive used or coastal area	High humidity or mountain area	Repeat tow- ing trailer
Engine oil	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Engine oil filter	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Fuel filter	15 months				I		
	24,000 km						
	15,000 miles						
Fuel line	15 months				I		
	24,000 km						
	15,000 miles						
Transmission oil	15 months						R
	24,000 km						
	15,000 miles	]					
ATF	15 months						R
	24,000 km	1					
	15,000 miles	]					
Front & rear differ-	15 months						R
ential oil	24,000 km	]					
	15,000 miles						
Brake line	15 months	I	I		I		I
	24,000 km						
	15,000 miles	1					
Brake fluid	15 months					R	
	24,000 km						
	15,000 miles						
Disc brake pads &	15 months	I	I		I		I
discs	24,000 km	1					
	15,000 miles	]					
Brake linings and	15 months	I	I		I		I
drums	24,000 km	1					
	15,000 miles						
Parking brake	15 months	I	1		I		1
	24,000 km	1					
	15,000 miles						
Suspension	7.5 months		I	I	I		I
	12,000 km	1					
	7,500 miles	<u>l</u>					
Axle boots &	7.5 months	I	I	I	I		I
joints	12,000 km	1					
	7,500 miles	1					
Steering system	7.5 months	I	I	I	I		I
(Power steering)	12,000 km	1					
	7,500 miles	1					